COMPETENCE B1180-1

The Versatile Built-In Oven

User Instructions



Dear customer

Please read these operating instructions carefully.
Pay particular attention to the section "Safety Instructions" on the first few pages. Please retain these operating instructions for later reference. Pass them on to possible new owners of the appliance.

The following symbols are used in the text:

Safety Instructions

Warning: Information concerning your personal safety.
Important: Information on how to avoid damaging the appliance.

Information and practical tips

Environmental information

1. These numbers indicate step by step how to use the appliance.

2. ...

3. ...

Before calling out an engineer to a fault please read the chapter "What to do if ..." as you may be able to resolve the problem yourself.
For further assistance contact your local AEG Service Force Centre, see the Chapter "Service and Spare Parts".

Your local AEG SERVICE FORCE centre is available at all times to deal with technical problems (addresses and telephone numbers are listed under "Customer Service Centres").

For additional information, also see the section "Service".

Printed on environmentally friendly paper.
Thinking ecologically means acting ecologically ...

CONTENTS

Operating Instructions 5

Safety 5

Disposal 7

Description of the Appliance 8
General Overview 8
Control Panel 8
Oven Features 9
Oven Accessories 10

Before Using for the First Time 11
Setting the Time 11
Initial Cleaning 12

Operating the Oven 13
Switching the Oven On and Off 13
Oven Functions 14
Inserting the Shelf and Universal Baking Tray 15
Attaching/Removing the Grill Pan Handle 16
Working with the Electronic Clock 17
Switching Off the Time Display 18

Usage, Tables and Tips 24
Baking 24
Baking Tables 26
Table: Desserts 28
Roasting 29
Table: Meat, roasting, casseroles 30
Table: Roasting, casseroles, au gratin 31
Grilling 33
Grilling Table 34
Defrosting 35
Defrosting Table 35

Cleaning and Care 36
Exterior of the Appliance 36
Oven Interior 36
Accessories 36
Shelf Support Rails 37
Oven Lighting 38
Cleaning the Oven Ceiling 39
Oven Door 40
Oven Door Glass 41

What to do if 43

Technical Data 44
Oven Interior Dimensions 44
Regulations, Standards, Directives 44

Installation Instructions 45
Safety Instructions for the Installer 45

Warranty conditions 51

Customer Service Centres 52

Index 54

Service & Spare parts 55

OPERATING INSTRUCTIONS

⚠ Safety

Electrical Safety

- The appliance may only be connected by a **registered specialist**.
- In the event of any faults or damage to the appliance: remove fuses or switch off.
- It is **not permissible** to clean the appliance with a steam or high pressure cleaner for safety reasons!
- **Repairs** to the appliance may **only be carried out by specialists**. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. If your appliance needs repairing, please contact your local AEG Service Force Centre or your specialist dealer.

Child Safety

- Never leave children unsupervised when the appliance is in use.

Safety whilst Using

- This appliance is intended to be used for cooking, frying and baking food in the home.
- Take care when connecting electric appliances to sockets nearby. Do **not** allow connecting leads to come into contact with hot rings or to catch beneath the hot oven door.
- **Warning: Risk of burns!** The interior of the oven becomes hot during use.
- Using ingredients containing alcohol in the oven may create an alcohol-air mixture that is easily ignited. In this case, open the door carefully. Do not have embers, sparks or naked flames in the vicinity when opening the door.

To Avoid Damaging Your Appliance

- Do not line your oven with aluminium foil and do not place a baking tray or dish on the oven floor, otherwise the oven enamel will be damaged by the resulting build up of heat.
- Juice from fruit that drips from baking trays will leave marks that cannot be removed. For very moist cakes, use the universal baking tray.
- Do not put any weight on the oven door when it is open.
- Never pour water directly into the hot oven. The enamel may be damaged.
- Using force, especially on the edges of the front glass panel, may break the glass.
- Do not store inflammable objects in the oven. They may ignite when the oven is switched on.
- Do not store moist food in the oven. The enamel may be damaged.

Disposal

Disposing of the packaging material

All materials used can be fully recycled.
Plastics are marked as follows:

- >PE< for polyethylene, as used for the outer wrapping and the bags inside.
- >PS< for polystyrene foam, e.g., as used for the padding materials. They are completely free of CFCs.

Disposal of old appliances

Warning: Before disposing of old appliances please make them inoperable so that they cannot be the source of danger.
To do this, disconnect the appliance from the mains supply and remove the mains lead.

To protect the environment, it is important that worn out appliances are disposed of in the correct manner.

- The appliance must not be disposed of with household rubbish.
- You can obtain information about collection dates or public refuse disposal sites from your local refuse department or council.

Description of the Appliance

General Overview



Control Panel



Oven Features



Relates only to appliances with a metal front:
Steam from the oven is fed out between the upper door edge and the control panel.

Oven Accessories

Combination shelf
For dishes, cake tins, roasting and grilling trays.



Grill pan with handle
Support for the grill tray as a collecting vessel for fat.



Grill tray
Insert for the grill pan for grilling smaller amounts of grilled food.



Before Using for the First Time

Setting the Time

The oven will only operate when the time has been set.

1. The time function indicator will flash after the appliance has been connected to the mains or following a power failure.



2. Using buttons ⊕ or ⊖ set the current time.



3. Wait for approx. 5 seconds.

The flashing will stop and the clock will show the set time.

The appliance is ready for use.

Initial Cleaning

Before using the oven for the first time you should clean it thoroughly.

Caution: Do not use any caustic, abrasive cleaners! The surface could be damaged.

To clean metal fronts use commercially available cleaning agents.

1. Turn the oven function switch to oven lighting.
2. Remove all accessories and the shelf support rails and wash them with warm water and washing up liquid.
3. Then wash out the oven with warm water and washing-up liquid and dry.
4. Wipe the front of the appliance with a damp cloth.

Operating the Oven

Switching the Oven On and Off



1. Turn the "oven functions" switch to the required function.
2. Turn the "temperature selection" switch to the required temperature.
   The yellow oven power indicator is illuminated while the oven is in use.
   The red temperature pilot light comes on while the oven is heating up.
3. To switch off the oven turn the "oven functions" switch and the "temperature selection" switch to the off position.

Cooling fan
The fan comes on automatically when the oven is in use in order to keep the surfaces of the appliance cool. Once the oven has been switched off, the fan continues running to cool down the appliance and then switches itself off automatically.

Oven Functions

The oven has the following functions:

Oven lighting

With this function you can **illuminate** the oven interior e.g. for cleaning.

The heating element is not in use.

Fan cooking

For **baking** on **up to three levels** at the same time.

The rear wall heating element is used and in addition the fan is switched on.

Defrost

To **begin to thaw and to defrost** such items as flan, butter, bread, fruit or other **frozen foods**.

For this function the fan operates **without** heating.

Grill

For **grilling** flat foods placed on the **middle of the shelf** such as steaks, escalopes or fish, or for **toasting**.

The grill heating element is in use.

Inserting the Shelf and Universal Baking Tray

Anti-tip device
All slide-in units have a small bulge on the left and right. This bulge is an anti-tip device and must always point to the rear of the oven.

Tray or universal baking tray:

The anti-tip device must point towards the rear of the oven.



Inserting shelf:
Insert the shelf unit with both guide rails pointing upwards. The anti-tip device must point downwards and be positioned to the rear of the oven compartment.



Inserting shelf and tray:
When the shelf unit and universal baking tray are used together, carefully place the shelf anti-tip device in the bulges on the tray.



Attaching/Removing the Grill Pan Handle

The handle is particularly useful for removing the grill pan and tray more easily from the hot oven.

Attaching the handle

Insert **the handle** at an angle from above into the recess in the side of the grill pan (1) lift it gently and then lower it (2) until you hear it click into place.



Warning: Risk of burning!
Important: Check that the handle is securely attached!

Removing the handle

Press the release button on the top of the handle (1) and lift up the handle (2) to remove it.



Important: Never leave the handle in the heated oven! Overheating can cause the handle to deform or break.

Working with the Electronic Clock



The electronic clock has the following functions:

Countdown
To set a countdown. A signal sounds after the time has elapsed.
This function does not affect the functioning of the oven.

Cook time
To set how long the oven is to be in use.

End time
To set when the oven is to switch off again.

Time
To set, change or check the time.
(See also section "Before Using for the First Time".)

General information

- Once a function has been selected the corresponding function indicator will flash for approx. 5 seconds. During this time the required times can be set using the ⊞ or ⊟ button.
- After the required time has been set the function indicator will flash again for approx. 5 seconds. After this the function indicator will stay on. The set time will begin to count down.
- The acoustic signal can be deactivated by pressing any button.
- The required oven function and temperature may be selected before or after setting the clock functions cook time ⊢| and end time |→|.
- When the cooking time has expired turn the oven function switch and the temperature selection switch back to the off position.

Switching Off the Time Display

By switching off the time display you can save energy.

Switching off the time display

Hold down any two buttons until the display becomes dark (approx. 10 seconds).

Switching on the time display

Hold down any two buttons until the time reappears in the display (approx. 10 seconds).

The display can only be switched off if none of the clock functions cook time ⊢| end time |→| or countdown ⊢→| are in use.

Countdown ⏭

1. Press selection button ⌄ repeatedly until the countdown function indicator ⏭ flashes.



2. Using the ⊕ or ⊖ button set the required countdown ⏭.
(Max. 2 hours and 30 minutes.)



After approx. 5 seconds the display will show the remaining time.
The countdown function indicator ⏭ is illuminated.



When the time has expired the function indicator will flash and an acoustic signal will sound for 2 minutes.

3. Press any button to switch off the acoustic signal.



Cook time ⊢→|

1. Press selection button ⌄ repeatedly until the cook time function indicator ⊢→| flashes.



2. Using buttons ⊕ or ⊖ set the required cooking time.



After approx. 5 seconds the display will revert to the time.
The cook time function indicator ⊢→| is illuminated.

When the time has expired the function indicator will flash, an acoustic signal will sound for 2 minutes and the oven will switch off.

3. Switch off the acoustic signal and the programme by pressing any button.



End time ⇥

1. Press selection button ⌄ repeatedly until the end time function indicator ⇥ flashes.



2. Using buttons ⊕ or ⊖ set the time at which you want the oven to switch off.



After approx. 5 seconds the display will revert to the time.
The end time function indicator ⇥ is illuminated.

When the time has elapsed the function indicator will flash, an acoustic signal will sound for 2 minutes and the oven will switch off.

3. Switch off the acoustic signal and the programme by pressing any button.



Cook time ↦| and End time →| combined

Cook time ↦| and end time →| can be used together if the oven is to switch on and off automatically at a **later time**.

1. Using the cook time ↦| function set the time required for the dish to cook.
In this case 1 hour.



2. Using the end time →| function set the time at which the dish is to be ready.
In this case 14:05.



The cook time ↦| and end time →| function indicators are illuminated and the time will appear in the display.
In this case 12:05.

The oven will switch on automatically at the calculated time.
In this case 13:05.

And will switch off again when the given time has expired.
In this case 14:05.

Changing TIME

The time can only be changed if neither of the automatic functions (cook time ⊢→| or end time →⊣) have been set.

1. Press selection button ⌄ repeatedly until the TIME function indicator flashes.



2. Using buttons ⊕ or ⊖ set the current time.



3. After approx. 5 seconds the function indicator will stop flashing and the clock will show the set time. The appliance is ready for use.



Usage, Tables and Tips

Baking

Use the fan cooking oven function for baking.

Important! Do not use a fat filter when baking!

Cake tins

- Light tins are suitable for fan cooking.

Shelf positions

- You can bake on up to 3 levels simultaneously using fan cooking:

1 Baking sheet:
Shelf position 3



1 Cake tin:
Shelf position 1



2 Baking sheets:
Shelf positions 1 and 4



3 Baking sheets:
Shelf positions 1, 3 and 5



General information

- Please note that the shelf positions are counted from bottom to top.
- Always place cakes in cake tins in the middle of the shelf.

Notes on the baking tables

In the tables you will find information on temperatures, cooking times and shelf positions for a selection of recipes.

- Ranges are given for the temperature and cooking time since these are dependent on the mixture, quantity and cake tin used.
- When baking several cakes on baking sheets or in cake tins, the cooking time can be 10-15 minutes longer.
- Moist items (e.g. pizzas & baking, fruit cakes, etc.) should be cooked on a maximum of two levels.
- When using for the first time, we recommend setting the lower temperature. If increased browning is required or the cooking time is too long, select a higher temperature.
- If you cannot find any specific information for one of your own recipes, use information on a similar recipe for guidance.
- Variations in the height of the item to be baked can lead to different degrees of browning at the start of baking. In this case, **please do not change the temperature setting**. Variations in the amount of browning will even themselves out during baking.

Switch off the oven 10-15 minutes before the end of the cooking time to make use of the residual heat.

Unless otherwise stated the information in the tables applies to a cold oven.

Baking Tables

Cakes, Biscuits, Bread, Pies	Fan Cooking		Time
	Shelf-position from bottom	Temp. °C	hr. : min.
Using cake tins			
Cakes in Pound Cake tins	1	**160-170**	1:00-1:10
Sandcakes/Cakes in loaf tins	1	**150-160**	1:15-1:30
Madeira cake	1	**150-160**	1:00-1:10
Dundee cake	1	**130-140**	2:30-3:00
Large Christmas cake (10")	1	**130**	4:30-5:00
Victoria Sandwich	1 + 4	**160**	0:25-0:35
Pastry cases	1 + 4	**170-190**	0:10-0:25
Bakewell tart	2	**160-170**	0:45-0:55
Swiss roll	**-**	**-**	0:10-0:15
Flans & quiches	3 or 2	**170-180**	0:30-0:50
Using baking sheets			
Short bread	1 + 4	**140-150**	0:40-0:50
Biscuits	1 + 4	**150-170**	0:15-0:25
Macaroons	1 + 4	**140-150**	0:25-0:35
Apple strudel	2	**170-180**[1]	0:30-0:50
Choux pastry buns	1 + 4	160-170[1]	0:20-0:35
Buns / cup cakes	1 + 4	**150-160**[1]	0:25-0:35
Scones	1 + 4	**190-200**[1]	0:10-0:15
Meringues	**3**	**75**	3:30-4:30
Sausage rolls	1 + 4	**170-180**[1]	0:20-0:35
Pizza	1	**180-200**	0:30-0:50

Cakes, Biscuits, Bread, Pies	Fan Cooking		Time
	Shelf-position from bottom	Temp. °C	hr. : min.
Bread			
Wholemeal bread	1	180-200[1]	0:40-0:45
White bread	1	180-200[1]	0:40-0:45

1) **Pre-heat oven.**
Select the lower temperature to start with, then select the higher one only if required.

Tips on Baking

	Tip
This is how to tell if your cake is cooked through	Push a wooden skewer into the highest point of the cake. When no more cake mixture sticks to the wood, you can switch off the oven and utilise the residual heat.
The cake collapses (is sticky, not properly cooked through, water marks)	Check your recipe. Next time use less liquid. Observe mixing times, particularly when using kitchen appliances.
The cake is too light	Next time select a dark cake tin or place the cake one level lower.
Cake with moist topping/ cake is not cooked through, is unevenly browned	Next time bake at a lower temperature and increase the cooking time.

Table: Desserts

Desserts	Fan Cooking		Time
	Shelf position from bottom	Temp. °C	Hr. : Min.
Apple pie	2	180-190	0:45-050
Rice pudding	2	130-140	2:00-2:30
Fruit crumble	2	160	0:50-1:10
Pineapple upside down cake	2	**160**	0:35-0:45
Pavlova	2	130	1:00-1:10
Baked custard	2	150-160	0:45-1:00
Baked apples	2	160-170	0:40-1:00
Bread and butter pudding	2	170-180	0:40-0:55
Apple charlotte	2	**180-190**	0:40-0:55
Soufflé - sweet/savoury	2	**170-190**[1]	0:30-0:45

1) Pre-heat oven.

The figures printed in bold indicate the **best oven function and temperature** to use in each case.

Select the lower temperature to start with, then select the higher one only if required.

Roasting

For roasting, use the fan cooking oven function.

Important: **Use the fat filter when roasting!**

Roasting Dishes

- Any heat-resistant dish is suitable for roasting.
- If the dish has plastic handles, ensure that the handles are heat-resistant.
- Large roasts can be roasted **directly on the meat tin or on the shelf with the meat tin underneath** (e.g. turkey, goose, 3-4 chickens, 3-4 knuckles).
- When roasting meat choose a dish which is just a little larger than the joint itself to retain the juices in a small area thus preventing fat from spitting and soiling the oven.
- We recommend roasting all lean types of meat **in a casserole with a lid** (e.g. veal, pork or beef pot roasts, frozen meat). This way the meat will remain moist.
- You can roast all types of meat that should have a crispy exterior **in a casserole without a lid** (e.g. pork, meat loaf, lamb, duck, 1-2 knuckles, 1-2 chickens, small poultry, sirloin, fillet, game).
- **Tip**: If you use dishes for roasting (particularly for small amounts), the oven will not get so dirty!

Shelf Positions

- Please see the following table for the shelf positions to use.

Notes on the Roasting Tables

Information is given in the table on suitable oven functions, temperature settings, cooking times and shelf positions for various types of meat. The cooking times are only for guidance.

- We recommend roasting meat and fish **in the oven from a weight of 1 kg**.
- The cooking time required is dependent on the type and quality of the meat.
- To stop juices that exude from the meat burning onto dishes, we recommend adding a little liquid in the roasting dish.
- Turn the roast after approx. 2/3 of the cooking time.

Switch off the oven 10-15 minutes before the end of the cooking time to make use of the residual heat.

Table: Meat, roasting, casseroles

Meat	Fan Cooking		Time
	Shelf position from down	Temperature °C	hrs. : min.
Pork			
Shoulder; leg; rolled; boned spare rib; loin of pork	2	**170-180**	0:30-0:35 per 450 g/1 lb plus 30-35 mins
Beef			
Inexpensive cuts	2	**160-170**	0:35-0:40 per 450 g/1 lb plus 15-20 mins
Prime cuts			
-rare	2	**170-180**[1]	0:15-0:20 per 450 g/1 lb plus 15-20 mins
-medium	2	**170-180**	0:20-0:25 per 450 g/1 lb plus 25-25 mins
-well done	2	**170-180**	0:30-0:35 per 450 g/1 lb plus 25-30 mins
Yorkshire pudding			
- small	3	**200**[1]	0:10-0:15
- large	2	**180-190**[1]	0:30-0:40
Lamb	2	**170-180**	0:30-0:35 per 450 g/1 lb plus 30-35 mins
Veal	2	**170-180**	0:30-0:35 per 450 g/1 lb plus 30-35 mins

1) Pre-Heat oven.
2) For joints of 5 lb & over eliminate the additonal time.
The figures printed bold indicate the **best oven function and temperature** to use in each case.
Select the lower temperature to start with, then select the higher one only if required.

Table: Roasting, casseroles, au gratin

Poultry, Game, Fish, Vegetables	Quantity approx.	Fan Cooking		Time
		Shelf position from down	Temperature °C	hrs. : min.
Casseroles, miscellaneous				
Casseroles	1 kg/2 lbs	2	**150**	2:30-3:00
Lancashire Hot Pot	1 kg/2 lbs	2	**150-160**	2:15-2:30
Moussaka	1 kg/2 lbs	2	**170-180**	0:40-0:50
Meat Loaf	675 g/ 1.5 lbs	2	**170-180**	1:00-1:10
Poultry/ Game				
Chicken	1 kg/2 lbs	2	**170-180**	0:50-1:10
Chicken	1.5 kg/3 lbs	2	**170-180**	1:15-1:30
Duck	1.5-2 kg/3.5-4 lbs	2	**180-190**	1:15-1:45
Goose	3.5-5 kg/ 8-10 lbs	2 or 1	**170-180**	2:30-3:00
Turkey	2.5-3.5 kg 5-7 lbs	2	**160**	1:30-2:00
Turkey	4-6 kg/ 8-13 lbs	2 or 1	**150-160**	2:30-4:00
Pheasant, Wild Duck, Rabbit	1 kg/2 lbs	3 or 2	**210**	0:30-1:00
Partridge/Pigeon	per 300-500 g	3 or 2	**190-200**	0:30-0:50
Fish (baked, steamed)				
Whole fish	1-1.5 kg/ 2-3 lbs	2	**160-170**	0:45-1:15

Poultry, Game, Fish, Vegetables	Quantity approx.	Fan Cooking		Time
		Shelf position from down	Temperature °C	hrs. : min.
Fish pies, bakes	750 g-1 kg/ 1.5-2 lbs	3 or 2	**170-190**	0:30-1:00
Vegetables				
Stuffed pepper/ aubergines		2	**180-190**	0:30-1:00
Au gratin dishes		3	**180-200**	0:15-0:45

Grilling

Use the grill oven function with a temperature of 275 °C for grilling.

Important: Always pre-heat the empty oven **for 5 minutes using the grill function**

It is not necessary to use the fat filter.

Ovenware for grilling

- For small amounts use the grill pan and the grill pan grid together for grilling.
- For larger amounts use the wire shelf and the meat tin together for grilling.

Warning: The **grill pan handle must be removed** whilst grilling! Always use oven gloves when removing or attaching the grill pan handle.

Shelf positions

- For grilling flatter foods, always use the **2nd shelf position from the top**.

Notes on the grilling table

The grilling times are for guidance only and are dependent on the type and quality of the meat or fish.

- Grilling is particularly suitable for flat pieces of meat and fish.
- Turn over pieces of meat or fish halfway through the grilling time.

Warning: Always grill with the oven door shut.

Grilling Table

Food		Shelf Level from down	Grilling Time minutes each side
Bacon rashers		4.	2-3
Beef burgers		4.	6-10
Chicken joints		4.	10-15
Chops:	Lamb Pork	4.	7-10 10-15
Fish:	Whole trout Hering Fillet plaice/cod	4.	8-12 4-6
Kebabs		4.	10-15
Kidneys:	Lamb/pig	4.	4-6
Liver:	Lamb/pig	4.	5-10
Sausages		4.	10-15 (turn as required)
Steaks:	rare medium well	4.	3-6 6-8 7-10

Defrosting

To defrost food, use the oven´s defrosting function at 30°C.

Defrosting dishes

- Put the food on a plate and put the plate on the tray.
- Use only parchment paper or film to cover the food. Do not use plates or dishes as they significantly increase the defrosting time.

Shelf levels

- For defrosting, insert the tray in the **2nd level from the bottom**.

Notes on the defrosting table

The table below gives you a few reference points on the defrosting times.

Defrosting Table

Meal	Defrosting time Min.	Standing time Min.	Note
Chicken, 1000 g	100-140	20-30	Place the chicken on an upside-down saucer on a large plate. Defrost open and turn after half the time, or defrost covered with film.
Meat, 1000 g	100-140	20-30	Defrost open and turn after half the time or cover with film.
Meat, 500 g	90-120	20-30	Defrost open and turn after half the time or cover with film.
Trout, 150 g	25-35	10-15	Defrost open
Strawberries, 300 g	30-40	10-20	Defrost open
Butter, 250 g	30-40	10-15	Defrost open
Cream, 2 x 200 g	80-100	10-15	Defrost open (Cream can also be whipped well if parts of it are still slightly frozen)
Flan, 1400 g	60	60	Defrost open.

Cleaning and Care

Warning: For safety reasons cleaning the appliance with a steam jet cleaner or high-pressure water cleaner is **not permissible**!

Exterior of the Appliance

Wipe the front of the appliance with a soft cloth dipped in warm soapy water.

- Do not use scourers, caustic cleaners or abrasive items.
- Use commercially available cleaners for metal fronts.

Oven Interior

Warning: The oven must be switched off and cold before cleaning.

Clean the appliance after each use. This is the easiest way to remove spills and prevents them being burnt on.

1. Switch on the oven lighting when cleaning.
2. Every time you use the oven, wipe it out afterwards with water and washing-up liquid, then dry. Do not use any abrasive items.
3. Remove stubborn marks with special oven cleaners.

Important: Always follow the manufacturer's instructions when using oven spray!

Accessories

Wash all slide-in units (shelf unit, baking tray, shelf support rails etc.) after each use and dry well. Soak briefly to make them easier to clean.

Shelf Support Rails

The shelf support rails on the left and right hand sides of the oven can be removed for cleaning the side walls.

Removing the shelf support rails
First pull the front of the rail away from the oven wall (1) and then unhitch at the back (2).





Fitting the shelf support rails

Important! The rounded ends of the guide rails must be pointing forwards!



To re-insert, first hook the rail into place at the back (1) and then insert the front and press into place (2).



Oven Lighting

Warning: There is a danger of electric shock! Prior to changing the oven light bulb:

– Switch off the oven!
– Remove the fuses in the fuse box or switch off the circuit breaker.

Place a cloth on the oven floor to protect the oven light and glass cover.

Replacing the oven light bulb/cleaning the glass cover



1. Remove the right shelf support rail.
2. Remove the glass cover by turning it anti-clockwise and then clean it.
3. If necessary:
   Replace bulb with a 40 watt, 230 V, 300 °C heat-resistant oven light bulb.
4. Refit the glass cover.
5. Insert the shelf support rail.
6. Remove the cloth from the oven.

Cleaning the Oven Ceiling

The upper heating element can be folded down to make it easier to clean the oven ceiling.

Folding down the heating element



Warning: Only fold down the heating element when the oven is switched off and there is no risk of being burnt!

1. Remove the side shelf support rails.
2. Grip the heating element at the front and pull it forwards and out over the support lug on the inner wall of the oven.
3. The heating element will now fold down.



Caution: Do not use force to press the heating element down! The heating element might break.

Cleaning the oven ceiling

Repositioning the heating element



1. Move the heating element back up towards the oven ceiling.
2. Pull the heating element forwards against the spring pressure and guide it over the oven support lug.
3. Settle it onto the support.
4. Insert shelf support rail.



Important: The heating element must be positioned correctly and securely on both sides above the support lug on the inner wall of the oven (2).

Oven Door

The oven door of your appliance may be removed for cleaning.

Removing the oven door



1. Open the oven door completely.
2. **Completely** fold back the **brass-coloured clamping lever** on **both** door hinges.
3. Grip the oven door with both hands on the sides and close it to about 3/4 **going past the point of resistance**.
4. Pull the door away from the oven (**Caution**: heavy!).
5. Place the door, with the outer surface downwards, on a soft, flat surface, for example a blanket, to avoid scratches.

Hanging the oven door

Caution: When hanging the door the clamping lever on **both** door hinges must be opened out!



1. With both hands take hold of the sides of the door from the side on which the handle is positioned.
2. Hold the door at an angle of approx. 60°.
3. Slide the door hinges **simultaneously** as far as possible into the two slots on the right and left at the bottom of the oven.
4. Lift the door up until resistance is met and then open fully.
5. Lift the brass-coloured clamping levers on both door hinges back to their original position.
6. Close the oven door.

Oven Door Glass

The oven door is fitted with three glass panels mounted one behind the other. The inner panels may be removed for cleaning.

Warning: Carry out the following steps only when the oven door is unhinged! When left on its hinges, the door could rise rapidly due to the lighter weight when the glass is removed and could cause injury.

Important: Using force, especially on the edges of the front glass panel, may break the glass.

Removing the top door glass

1. Unhinge the oven door and place it on a soft, flat surface with the handle facing down.
2. Take hold of the upper glass panel at the lower edge and slide it against the spring pressure in the direction of the oven door handle until it is free at the base.
3. Raise the panel **gently** at the base and pull out.



Removing the middle door glass

1. Grip the bottom edge of the middle glass panel and push it in the direction of the oven door handle until it is free at the base.
2. Raise the panel gently at the base and pull out.



Clean the glass door panels

Inserting the middle door glass



1. Insert the middle glass panel at an angle from above into the section of the door in which the handle is located.
2. Lower the middle glass panel and slide it under the lower bracket towards the lower door edge as far as it will go.

Inserting the upper door glass



1. Insert the upper glass panel at an angle from above into the section of the door in which the handle is located.
2. Lower the glass panel. Lay the panel against the spring on the lower door edge in front of the retaining section on the handle side and **slide it under the retaining section**. The glass panel must be firmly in position!

Re-hang the oven door

What to do if ...

Symptom	Possible cause	Solution
The oven does not heat up.	The oven has not been switched on.	Switch on the oven.
	The time has not been set.	Set the time.
	The necessary settings have not been made.	Check the settings.
	The circuit breaker (at the household fuse box) has tripped or the fuse has blown.	Check the fuse. If the circuit breaker trips or the fuse blows several times please call an approved electrician.
The oven lighting does not come on.	The oven light bulb has blown.	Replace the light bulb in the oven (see Cleaning and Care).

If you cannot rectify the fault with the help of the information given above please contact your local Service force Centre.

Warning: Repairs to the appliance must be carried out by qualified service engineers! Improper repairs can give rise to significant hazards for the user. If your appliance needs repairing, please contact your local AEG Service Force Centre.

In-guarantee customers should read the above section, as the engineer will make a charge if the fault is not a mechanical or electrical breakdown.

Information for appliances with a metal front:

Due to the cold front of your appliance the inner door glass may steam over briefly if you open the door during or shortly after baking or roasting.

Technical Data

Oven Interior Dimensions

Height x Width x Depth	31 cm x 41 cm x 41 cm
Capacity (usable capacity)	52 l

Regulations, Standards, Directives

This appliance meets the following standards:

- EN 60 335-1 and EN 60 335-2-6
  relating to the safety of electric appliances for household use and similar purposes and
- EN 60 350 and
- DIN 44546 / 44547 / 44548
  relating to the operating features of household electric cookers.
- EN 55014-2
- EN 55014
- EN 61000-3-2
- EN 61000-3-3
  relating to basic requirements for electromagnetic compatibility protection (EMC).

CE This appliance complies with the following EC directives:

- 73/23/EEC dated 19.02.1973 (Low Voltage Directive)
- 89/336/EEC dated 03.05.1989 (EMC Directive including Amending Directive 92/31/EEC).

INSTALLATION INSTRUCTIONS

Important: Any electrical installation work must be carried out by a qualified electrician/competent person.

The oven must be installed according to the instructions supplied.

Safety Instructions for the Installer

- Protection against access to live parts must be guranteed by the installation.
- The unit in which the appliance is fitted must satisfy the requirements of DIN 68930 in respect of stability.
- This oven must be installed by qualified personnel to the relevant Standards.
- This oven is heavy. Take care when moving it
- Remove all packaging, both inside and outside the oven before using the oven.
- Do not attempt to modify the oven in any way.
- The built-in cooker and hobs are fitted with special connector systems. They may only be combined with units of the corresponding system.



1 This oven can be installed either in-column as shown or under a counter



2


alternativ 100
560
590
300
70

3


230V ... 240V ~
230V...240V~
L
N
PE
330 211 306

4



5



6



7



8



9

WARRANTY CONDITIONS

Great Britain

Guarantee Conditions

AEG offer the following guarantee to the first purchaser of this appliance.

1. The guarantee is valid for 12 months commencing when the appliance is handed over to the first retail purchaser, which must be verified by purchase invoice or similar documentation.
   The guarantee does not cover commercial use.
2. The guarantee covers all parts or components which fail due to faulty workmanship or faulty materials. The guarantee does not cover appliances where defects or poor performance are due to misuse, accidental damage, neglect, faulty installation, unauthorised modification or attempted repair, commercial use or failure to observe requirements and recommendations set out in the instruction book.

   This guarantee does not cover such parts as light bulbs, removable glassware or plastic, dust bags or filters.
3. Should guarantee repairs be necessary the purchaser must inform the nearest customer service office (manufacturer´s service or authorised agent). AEG reserves the right to stipulate the place of the repair (i. e. the customer´s home, place of installation or AEG workshop).
4. The guarantee or free replacement includes both labour and materials.
5. Repairs carried out under guarantee do not extend the guarantee period for the appliance. Parts removed during guarantee repairs become the property of AEG.
6. The purchaser´s statutory rights are not affected by this guarantee.

European Guarantee

If you should move to another country within Europe then your guarantee moves with you to your new home subject to the following qualifications:

- The guarantee starts from the date you first purchased your product.
- The guarantee is for the same period and to the same extent for labour and parts as exist in the new country of use for this brand or range of products.
- This guarantee relates to you and connot be transferred to another user.
- Your new home is within the European Community (EC) or European Free Trade Area.
- The product is installed and used in accordance with our instructions and is only used domestically, i. e. a normal household.
- The product is installed taking into account regulations in your new country.

Before you move please contact your nearest Customer Care Centre, listed below, to give them details of your new home. They will then ensure that the local Service Organisation is aware of your move and able to look after you and your appliances.

France	Senlis	+33 (0) 44 62 29 29
Germany	Nürnberg	+49 (0) 911 323 2600
Italy	Pordenone	+39 (0) 1678 47053
Sweden	Stockholm	+46 (0) 8 738 7910
UK	Slough	+44 (0) 1753 219899

CUSTOMER SERVICE CENTRES

Great Britain

For general enquiries or information regarding AEG appliances contact:
Customer Services Department
AEG Domestic Appliances
55-77 High Street
Slough
Berkshire
SL1 1DZ
Tel.: 08705 350 350

INDEX

A

Accessories 15

C

Cleaning
- accessories 36
- initial cleaning 12
- oven door 40
- shelf support rails 37

Clock 17
- changing time 23
- cook time 20
- countdown 19
- end time 21
- setting the time 17

Control panel 8
Customer Service 52

D

Defrost 14
Description of the appliance 8
Disposal 7
Door 40

F

Fan cooking 14

G

Grill 14

I

Insert anti-tip 15

O

Oven
- Accessories 10
- door 40
- functions 14
- light 38
- operating 13

R

Repairs 5

S

Safety 5
Shelf 15
Shelf support rails 37
Steam vent 9
Switching off the time display 18

T

Tables and tips 24

U

Universal baking tray 15

W

Warranty 51
What to do if 43

SERVICE & SPARE PARTS

If you wish to purchase spare parts or require an engineer, contact your local AEG Service Force Centre by telephoning:

08705 929 929

Your telephone call will be automatically routed to the Service Centre covering your post code area.

When you contact the Service Centre they will need the following information:

1. Your name & address, including post code.
2. Your telephone number
3. Clear and concise details of the fault.
4. The model, serial and production number. This information can be found on the rating plate. The rating plate is on the inner edge of the door on the right.
5. Date of purchase. Please note that it will be necessary to provide proof of purchase for any in guarantee service call.



In-guarantee customers should ensure that the chapter headed „Remedying Faults" has been read, as the engineer will make a charge if the fault is not a mechanical or electrical breakdown.

Customer Care

For general enquiries concerning your AEG appliance or for further information on AEG products please contact our Customer Care Department by letter or telephone at the address below or visit our website at www.aeghome.co.uk.

Customer Care Department
AEG Domestic Appliances
55-77 High Street, Slough
Berkshire, SL1 1DZ

Tel. 08705 350350 (*)

(*) Call may be recorded for training purposes

AEG Hausgeräte GmbH
Postfach 1036
D-90327 Nürnberg

http://www.aeg.hausgeraete.de

© Copyright by AEG

822 947 666 -A- 160701-04